

SULZER AIR JET RELAY NOZZLES

		
<p>14.205.105 Sulzer L5000 / L5100 Air jet nozzle without base, 19 holes, Titanium coated, screw-in connection</p>	<p>14.105.111A Sulzer L5000 / L5100 Air jet nozzle with ALU base, 19 holes, Titanium coated, threaded connection joint M8 + copper ring in base, smooth</p>	<p>14.105.111B Sulzer L5000 / L5100 Air jet nozzle with ALU base, 19 holes, Titanium coated, threaded connection joint M8 + copper ring in base, grooved at the bottom</p>
		
<p>15.105.107 Sulzer L5200 Air jet nozzle with base, 19 holes, Titanium coated, screw-in connection with M8 thread</p>	<p>15.214.107 Sulzer L5200 Air jet nozzle without base, 19 holes, Titanium coated, screw-in connection with M8 thread</p>	<p>15.214.207 Sulzer L5200 Air jet nozzle with base, 19 holes, Titanium coated, threaded connection joint M8 + copper ring in base</p>